Installation

The thermostat must not be fitted behind curtains, behind radiator panelling, in window recesses, underneath window seats or in convector shafts, etc.

Retention pins

The valve comes with one loose plastic retention pin with the thermostat can be locked.

Limiting the highest setting

- set the index value regulator to the desired position
- place the retention pin into the opening situated on the upper value side

Limiting the lowest setting

- set the index value regulator to the desired position
- place the retention pin into the opening situated on the lower value side

Locking the setting

- set the index value regulator to the desired position
- place the retention pin into the opening situated in the index

Fitting of the thermostat head

- set index value to position 5
- screw on head nut securely using cylinder wrench but do not overtighten